

# Sample Program for Windows

Published on Mar. 3, 2021  
Version 1.01

## 1. Contents

|  |   |
|--|---|
| 1. Contents .....  | 1 |
| 2. Settings .....  | 2 |
| 2-1. Functions available .....                                 | 2 |
| 2-2. Functions unavailable .....                               | 2 |
| 2-3. Controls on the camera .....                              | 2 |
| 3. Operation when connected to a camera / while shooting ..... | 3 |
| 3-1. Connecting .....  | 3 |
| 3-2. Operation when shooting still images .....                | 3 |
| 3-3. Operation when recording movies .....                     | 3 |
| 3-4. Using AF-S .....  | 3 |
| 3-5. Using AF-C .....  | 3 |

## 2. Settings

Settings for the sample program.

### 2-1. Functions available

Functions that can be set from the sample program are:

- Shutter speed
- Aperture
- ISO sensitivity (Auto / Manual)
- White balance
- Color mode

### 2-2. Functions unavailable

Functions that can not be set from the sample program are:

- Shooting mode  
It will be fixed to M: Manual Exposure
- Shutter speed display  
It will be fixed to speed
- Other settings  
It will be fixed on default settings

### 2-3. Controls on the camera

Controls on the camera are:

- Aperture  
Unless the aperture ring is set to auto, the value of the aperture ring will be prioritized.
- Focus  
Cannot use AF when set to MF

No other buttons or dials are available to use.

### **3. Operation when connected to a camera / while shooting**

The operation when connecting to a camera with the sample program.

#### **3-1. Connecting**

It will automatically connect to the camera detected.

#### **3-2. Operation when shooting still images**

Still image shooting is available by pressing the Still button.

Still images will be saved to the PC only.

Still images will be saved to the picture folder of the PC regardless the SD card is used or not.

All still images will be saved as JPEG (FINE) format.

#### **3-3. Operation when recording movies**

Video recording will start when the REC button is pressed. The recording will end when pressed again. The recorded video will automatically be transferred to the PC.

The video file will be saved in the pictures folder of the PC.

All videos will be saved as MOV (GOP) format.

As the video recorded on the SD card is transferred to the PC, video recording cannot be performed without the SD card.

#### **3-4. Using AF-S**

When the AF-S button is pressed, the AF-S operation will be performed once.

#### **3-5. Using AF-C**

The AF-C operation will start by pressing the AF-C button. It will end the operation when pressed again.